
#### CABLE CONNECTION

### STEP 8. MOTHERBOARD CONNECTIONS

#### **HD AUDIO & USB 3.0 CABLES**

a. CONNECT THE CABLES TO THE MOTHERBOARD



#### FRONT I/O HEADER CONNECTIONS

INSTALLATION GUIDE

**b.** CONNECT THE CABLES TO THE FRONT I/O HEADER ON THE MOTHERBOARD
(SEE FRONT I/O HEADER DIAGRAM FOR GENERAL REFERENCE)






Diagram is a general overview. For a more accurate overview of your motherboard, please consult that motherboards' manual.

## STEP 9. RGB LIGHTING - P300 ONLY (P300A DOESN'T COME WITH RBG CONTROL)

**a.** CONNECT THE SATA CABLE TO THE POWER SUPPLY



#### CONNECT MORE RGB PRODUCTS

**b.** CONNECT RGB CONNECTOR TO RGB PRODUCTS



#### SYNC YOUR CASE LIGHTING TO THE MOTHERBOARD


C. CONNECT MOTHERBOARD RGB ADAPTER\* TO THE MOTHERBOARD \*SOLD SEPERATELY (PH-CB\_RGB4P)



## OPTIONAL UPGRADES

VERTICAL GPU BRACKET (PH-VGPUKT-02)

THE PHANTEKS VERTICAL GPU
BRACKET CAN BE EASILY
INSTALLED IN THE REAR PCI-SLOT
AREA WITHOUT MODIFICATIONS.
FOLLOW THE INSTRUCTIONS THAT
COME WITH THE VERTICAL GPU
BRACKET.




### INTRODUCTION

Thank you for choosing Phanteks. Please take a moment to carefully go through the manual. Phanteks will not take responsibility for any damages incurred due to incorrect installation or usage of this product.

This manual is applicable for the following products:

PH-EC300PTG PH-EC300ATG

# INCLUDED ACCESSORIES



### PRODUCT OVERVIEW


CLEARANCE

CPU Cooler Height 165 mm
PSU Clearance 200 mm
GPU Clearance 355 mm
Front radiator | 240: 122x315 mm
Front radiator | 280: 142x315 mm


REAR
120 FAN
120 RAD

TOP
120 140 FAN FAN





## ECLIPSE P300A FRONT I/O



### FRONT I/O FEATURES


| English   | Francais  |
|---|---|
| 1. Headphone<br>2. Microphone<br>3. USB 3.0<br>4. RGB Control<br>5. Power Button<br>6. Reset Button | 1. Casque 2. Microphone 3. USB 3.0 4. RGB Contrôle 5. Bouton d'alimentation 6. Bouton de réinitialisation |
| Deutch  | Espanol   |
| Deuten  | Espanoi   |

#### PANEL REMOVAL


There are three panels that can be removed from the P300(A) Chassis; the left side tempered glass panel, the right side panel and the front panel. Follow these steps below.

# STEP 1. LEFT SIDE PANEL


a. LOOSEN THUMB SCREWS AND SLIDE TO THE LEFT.









**C.** PULL UPWARD TO REMOVE.



## PANEL RE-INSTALLATION

FOLLOW STEPS IN REVERSE ORDER.








## STEP 3. FRONT PANEL

LOOSEN THUMB SCREWS AND SLIDE THE SIDE PANEL OFF.

STEP 2. RIGHT SIDE PANEL



REMOVE FRONT PANEL BY PULLING ON IT FROM BELOW




## HARDWARE INSTALLATION

### STEP 4. MOTHERBOARD

INSTALL THE ATX MOTHERBOARD WITH 9 MOTHERBOARD SCREWS





O Micro - ATX





If installing a Micro-ATX motherboard, install the extra standoff supplied and consult your motherboard manual for further instructions.

## STEP 5. POWER SUPPLY

INSERT THE POWER SUPPLY INTO THE CHASSIS AND THEN SECURE THE POWER SUPPLY WITH 4 PSU SCREWS









# **STEP 6.** 2.5" SSD

INSTALL THE SSD DRIVE WITH 4 SSD SCREWS AND MOUNT INTO THE CHASSIS.

A SECOND OPTIONAL SSD BRACKET CAN BE INSTALLED. 2.5" SSD DRIVES CAN ALSO BE INSTALLED INTO THE 3.5" DRIVE BAYS.









# **STEP 7.** 3.5" HDD

REMOVE THE HDD TRAY BY PULLING OUTWARD. INSTALL THE HDD DRIVE IN THE TOOLLES HDD TRAY AND SLIDE THE MOUNTED HDD TRAY BACK INTO THE CHASSIS.







The HDD Tray can also hold a 2.5" SSD