







PACKAGE CONTENTS

For latest version check www.Phanteks.com

	GLACIER GB2080FE QTY: 1		Thermal Pads QTY: 2		Thermal Compound PH-NDC-01 QTY: 1
	GLACIER Stop Fitting QTY: 2		M2,5x5 Screws QTY: 15 Washers QTY: 15		Phanteke RGB Cable QTY: 1 RGB Motherboard Adapter QTY: 1


⚠ WARNING - This product is intended for advanced users. Improper installation may result in damage to your equipment. While all efforts have been made to provide the most comprehensive information possible, Phanteke assumes no liability expressed or implied for any damage(s) occurring to your components as a result of using Phanteke cooling products, either due to mistake or omission on our part in the below instructions, or due to failure or defect in the Phanteke cooling products. Do not disassemble the water block. Warranty will be voided.



Turn off the power to your system and discharge your body's static electric charge before proceeding with the installation procedure. If you do not feel comfortable with performing the installation procedure, consult a qualified computer technician.

STEP 1. REMOVING STOCK COOLER

Unscrew all highlighted screws to remove the backplate and stock cooler.

⚠ Make sure to unplug the LED and Fan cables when you remove the stock cooler.


 Use the EVA-Foam from the box to use as a base for your installation process.



STEP 2. APPLYING THERMAL COMPOUND


Clean off the original thermal compound. We recommend using isopropanol alcohol.

Apply a drop of the Phanteke Thermal Compound to the center of the GPU chip.




STEP 3. APPLYING THERMAL PADS

Remove the protective film and place the thermal pads on correct position on the PCB.



! Make sure to remove the protective film on both sides of the thermal pads.




STEP 4. MOUNT THE WATER BLOCK

Carefully position the water block onto the graphics card. Align the mounting holes on the PCB with the holes on the water block.

Secure the water block with 13 M2,5x5mm screws and washers to the PCB.



! Make sure to lay the GPU with the water block flat down without resting on the PCI bracket.



STEP 5. CONNECT RGB LIGHTING

Connect the RGB cable to the 2 RGB strips in the water block.

Connect to RGB-equipped motherboard:



STEP 6. INSTALLING FITTINGS

Install G1/4 threaded male fittings and close the remaining ports with the two included Stop Fittings.

! Always perform a leak test before providing power to any system components.

